



Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Peça de reposição - Parti di ricambio - Reservedele - Reservdelar Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Elast. Verbindung	Elastic connector	JP43705
②	Niveaufassung	Level control	JP43712
③	Flansch	Flange	JP43706
④	Steuerung	Control unit	
	compli 425/2		JP45789
	compli 435/2		JP45790
⑤	Pumpe	Pump	
	compli 425/2		JP45781
	compli 435/2		JP45782
⑥	Rückschlagklappe	Reflux valve	JP43707
⑦	Steuerungsplatine	Control board	
	compli 425/2		JP47717
	compli 435/2		JP47303
⑧	Basisplatte	Base plate	JP43711
⑨	Überschiebmuffe	Collar	JP47287
⑩	Dichtband	Sealing tape	JP47966
⑪	Pumpenlüftung	Pump ventilation	JP43710
⑫	Wartungsdeckel	Service lid	JP42798
⑬	Klemmflansch	Clamping flange	JP43708
⑭	Auftriebssicherung	Anti floating	JP43709
⑮	Steckdichtung	Plug in seal	JP45099
⑯	Behälter	Tank	JP44859

43136-02



①	Leitung	Cable	JP43717
②	Stator + Gehäuse	Stator + Housing	
	25/2		JP44008
	35/2		JP46211
③	Rotorwelle	Rotor shaft	
	25/2		JP48339
	35/2		JP48340
④	Gleitringdichtung	Mechanical seal	JP46567
⑤	Lagersatz	Bearing set	JP46214
⑥	Lagerschild	Bearing housing	JP43726
⑦	Dichtungssatz	Seal set	JP46807
⑧	Lauftrad	Impeller	
	25/2		JP48359
	35/2		JP48360
⑨	Wellenabdeckung	Shaft cover	JP47043
⑩	Motorabdichtung	Motor seals	JP46806
⑪	Schraubensatz	Screw set	JP47291
⑫	Ölschraube	Oil screw	JP46046

a	10x O-Ring 38x3,5	JP48109
b	10x O-Ring 10x2,5	JP48088